


Streetlight Point-of-Disconnect Diagram



Customer is responsible for:

- Providing and installing a junction box or pedestal, conduit, fusing and customer-owned wire. The junction box or pedestal must be strong enough for incidental traffic areas
- Coordinating with Rocky Mountain Power on junction box or pedestal location and all digging within the vicinity of Rocky Mountain Power facilities
- Ensuring that construction of new or remodeled installations conform to applicable provisions of the NEC State Rules, as well as city and county codes

Rocky Mountain Power is responsible for:

- Installing and connecting wire from Rocky Mountain Power facilities to the point of disconnect.



NOTE:

THIS SHEET OF INFORMATION IS PROVIDED BY ROCKY MOUNTAIN POWER.
CONTRACTOR IS RESPONSIBLE TO VERIFY CORRECT SPECIFICATION AND REQUIREMENTS.

1	CC	UPDATE	04/2010		<p>STANDARD DETAIL</p> <p>SL-7</p> <p>STREET LIGHT</p> <p>POINT-OF-DISCONNECT DIAGRAM</p>
NO.	AUTHORIZED BY	REVISIONS	DATE		